

1. Receiver (FFL only)
2. Left ejector
3. Right ejector
4. Ejector screw (2)
5. Loading trap
6. Loading trap spring
7. Loading trap spring screw
8. Loading trap stop screw
9. Side plate screw (2)
10. Hammer
11. Hammer roller
12. Hammer roller pin
13. Hammer safety pin
14. Hammer pin

15. Tang
16. Tang screw
17. Trigger
18. Trigger spring
19. Trigger spring screw
20. Main spring
21. Main spring screw
22. Magazine stop spring
23. Magazine stop
24. Magazine stop springscrew
25. Bolt
26. Top cover
27. Top cover screw
28. Extractor

29. Extractor pin
30. Firing pin
31. Firing pin lever
32. Firing pin lever pin
33. Slide
34. Carrier
35. Carrier screw
36. Locking brace
37. Locking brace pin
38. Barrel (round)
39. Barrel (half round)
40. Barrel (octagon)
41. Standard magazine tube
42. Standard magazine tube plug

43. Magazine spring
44. Follower
45. Magazine lug
46. Rifle tube screw
47. Forend stock wood R
48. Forend stock wood L
49. Grip escheution (4)
50. Grip screw (4)
51. Butt stock
52. Butt plate, Crescent or Carbine
53. Butt plate screw (2)
55. Trigger and stop pin

